

Instructions + Safety Information

PD-2136 – Art. 88882255

For your safety, please read this manual carefully before installation or using. Keep this safety instructions and forward it when you forward the power supply.

Intended use

- This product is only for indoor use as charger for suitable devices.
- Don't use or store this product close to water or in humid rooms.
- Don't use this product close to heat. The additional heat could cause overheating or fire.

Danger and protection

- Don't use the device if the pins are damaged.
 - In case of strange noise or smell, pull the power cord out of the socket or switch off the fuse.
 - Don't open the housing of the product (fire hazard/ electric strike).
 - Don't insert any items into the USB socket.
 - Don't remove the cable with wet hands (electric strike).
 - Don't use the product with wet hands (electric strike).
 - Remove charger from socket in case of longer non-use (could led to overheating, fire hazard or electric strike).
 - Use only faultless sockets installed from authorized personnel.
 - Look for sufficient airflow to avoid overheating or fire.
 - Leave service or cleaning only authorized, qualified personnel.
- Maintenance
- The charger generally needs no maintenance which requires opening of the housing or working inside the power supply.

Disposal

If you want to replace your charger or need to dispose of it, please do not dispose of it in your household waste, but take it to

a special collection point for old electrical appliances. If you have any questions, please contact your local authority or ask your specialist dealer. Please dispose of any cardboard and plastic packaging waste in the appropriate collection containers for your household waste.

Maintenance

The charger generally needs no maintenance which requires opening of the housing or working inside the power supply.

Warranty terms

We provide a 24-month warranty on our product from the date of purchase, provided it is used properly. To process a warranty claim, please contact your retailer with your proof of purchase. Please visit our website at www.inter-tech.de – Information – Warranty Terms and Conditions for the full terms and conditions and exclusions.

Use

To start using the charger, remove it from the packaging and check it for damage. Plug the charger into a power outlet and connect it to your device using a USB-C cable. Make sure that your device is suitable for charging with USB chargers and that the maximum output power of the charger is not exceeded.

Contact

Inter-Tech Elektronik Handels GmbH
Hainhauser Weg 93
D-30855 Langenhagen
Germany
Tel: +49 511 72667830
Fax: +49 511 72667837
Email: vertrieb@inter-tech.de
Web: www.inter-tech.de

For technical support, please use only the ticket system on our website.

Technical data:

Input	Voltage	100 - 240V~
	Frequency	50/60Hz
	Current	0.8A
Output	5V=	3A
	9V=	3A
	12V=	2.91A
	15V=	2.33A
	20V=	1.75A
	USB C1 +C2	5V 3A (15W)
Standby	<0.1W	
Efficiency	> 87%	
Protection	Overvoltage protection	
	Overload protection	
	Overcurrent protection	
	Short circuit protection	
Environmental	Temperature	0°C - 40°C Operation -20°C - 40°C Storage
	Humidity not condensing	5% - 90% Operation 0% - 95% Storage