

Manual

Mouse/ Keyboard Desktop Set

KB-118



1	Important information	3
1.1	Scope of delivery	3
1.2	Symbols	3
2	Safety	4
2.1	Intended use	4
2.1.1	Environmental	4
2.1.2	Disposal	4
2.2	General information	4
2.3	Danger and protection	5
3	Technical data	6
3.1	Features	6
3.2	Electric connection	6
3.3	Technical data	6
4	Installation	7
5	FAQ	8
6	Maintenance	9
7	Disposal	9
8	Warranty terms	10
9	Contact	11

1 Important information




1.1 Scope of delivery

1x Keyboard

1x Mouse

Manual

1.2 Symbols

Symbol	Meaning
	Use and results of safety information
	Indicates dangerous situations which can cause injury or death
	Indicates possible damage of property



2 Safety

2.1 Intended use

2.1.1 Environmental

This device is only for indoor use and connection to computers.

Don't use or store that device in humid rooms or close to water.

Don't use it close to heating. Additional heat can cause damage or fire.

2.1.2 Disposal

Don't dispose the device in the regular bin.

Read also chapter 7.

2.2 General information

Please read this manual carefully before installing or using this product.

Keep this manual and pass it when passing the product.

Please follow the instructions and warnings of this manual before using the product.

The inobservance of this manual can effect violations and damage.

We disclaim liability for violations and damages caused by inobservance of this manual.



2.3 Danger and protection

Don't apply pressure to the device.

Don't use it with wet hands.

Using keyboard and mouses can cause health effects to hands, wrists, arms, shoulders, neck and back.

Take precautions against these effects:

Adjust your sitting position to optimal position for torso, arms and hands.

Take regular breaks for physical training.

Change your sitting position more often.

Look for the right distance between Monitor, mouse and keyboard.

Adopt a natural attitude of wrist and shoulders.

In case of pain, prickling or numbness during or after using keyboard and/ or mouse, please contact a doctor.



3 Technical data

3.1 Features

Wired keyboard, 103 keys

Wired, optical mouse with 1000 dpi

3.2 Electric connection

Keyboard by USB

Mouse: by USB

3.3 Technical data

Keyboard

Connection	USB
Keys	103
Dimension	44,6 x 13,7 x 2,5 cm
Weight	380 g
Key pressure	55 +/- 7 g
MTBF	> 3 Million

Mouse

Connection	USB
Resolution	1000 dpi
Keys	3
Dimension	11,6 x 6,0 x 3,40 cm
Weight	75 g
Key pressure	70 -80 g



Environmental temperature	0-40°C	Use
	-20-60°C	Store
Environmental humidity	10-90%	Use
	< 93%	Store

4 Installation

1. Take out the devices and check package content for completeness and damages.

In case of missing parts or external damages, please contact your local dealer for replacement.

Please keep the original package for shipping in case of warranty issue.

2. Connect mouse and keyboard to a free USB port of your computer. Both are compatible to all kind of USB ports.
3. The computer will recognize mouse and keyboard automatically. The installation will have been finished and you can use the devices.

Problem	Possible reason	Repair
Mouse and/ or Keyboard won't work	USB plug not correctly fixed	Check if the USB plug is fixed correctly.
	USB port defect	Check with another device if the USB port is working.



6 Maintenance

Mouse and keyboard need no maintenance by opening the devices.

In the course of time dust can cause contamination of the optical sensor at the backside of the mouse. Therefore clean the sensor from time to time by blowing out.

Contamination at the top of mouse and keyboard can be cleaned with a damp rag.

Don't clean mouse and keyboard with a wet rag. Infiltrating water could cause short circuit and damage the devices.

7 Disposal

Please dispose your product by using the special discharge point for electronic waste. Please ask your municipality or disposal company in case of further questions.

Cardboard and plastic of packaging can be disposed by using the according way of disposal.



8 Warranty terms

Inter-Tech grants 24 months warranty by proper use up from the date of purchase.

In case of warranty issue please contact your local dealer or the dealer from which you bought the product.

We will grant no warranty by:

Missing or damaged warranty seal,

Negligent behavior,

Improper use,

Nonobservance of the manual,

External violence,

Acts of god,

Damages caused by manipulation, upgrading, updating or reconstruction of hardware or software

Damages caused by other harm,

In case of data loss Inter-Tech will only be liable at wanton negligence or deliberate intention or, in all other cases, only for the recovery of data from a continuous, daily backup. Inter-Tech does not assume liability for all other matters.

Please look also at our complete warranty terms on our website.



9 Contact

Inter-Tech Elektronik Handels GmbH

Hainhaeuser Weg 93

D-30855 Langenhagen, Germany

Tel: +49 511 72667830, Fax: +49 511 72667837,

Email: vertrieb@inter-tech.de

Web: www.inter-tech.de

This product complies to directives 2014/30/EU and 2011/65/EG of the parliament of the European Community.

The declaration of conformity is placed at our website:
Service & Support/ Downloads/ Declaration of conformity

www.inter-tech.de